

Designer Rust Kit Basic Application

step 1.



Products: SetCoat Metallic Bronze®, Designer Rust Kit

Tools: Chip Brush

step 1. Apply any black or silver paint as a base coat.

Allow to dry completely.

step 2.



step 2. Apply an ample amount of "Designer Rust" to entire surface.

Allow to dry 30 minutes.

step 3.



step 3. Lightly brush "Rust Glaze" over raised details to create contrast.



2700 Industrial Avenue Two, Fort Pierce, Florida 34946
800-270-8871 □ www.fauxfx.com
©2020 Faux Effects International, Inc. All Rights Reserved

