



SetCoat Metallic® Basic Application

Products: SetCoat Metallic®

Tools: 1/4" Nap Roller, Tape

- step 1. Apply first coat of SetCoat Metallic® by rolling with medium pressure. Immediately proceed to step two
- step 2. Back roll one direction overlapping with light to no pressure. Making sure that the finish is applied evenly with no roller marks. Allow to dry completely.
- step 3. Apply second coat by rolling with light pressure. Immediately proceed to step four
- step 4. Back roll one direction overlapping with no pressure. Making sure that the finish is applied evenly with no roller marks. Allow to dry completely.

